


Aggiornamento Firmware

TF 卡固件升级操作步骤如下:

TF card firmware upgrade :

1、使用 USB 读卡器将 TF 卡格式化，仅支持 FAT 文件系统；

1. Format the TF/SD Card by USB card reader (Support FAT document system only



2、拷贝升级文件到 TF 卡，升级文件名为 `update.img`；

2. Copy the upgrade document "update.img" to TF/SD card

3、将附带升级文件的 TF 卡插入摄像头的 TF 卡槽内，启动摄像头，当绿灯常亮，表示已进入升级状态（正常启动情况下为红灯闪烁）；

3. Insert the TF/SD card that with upgrade document "update.img" into device TF/SD card slot and plug in power and start the device .It is upgrading when green light in stable condition (When start the device the Red Light is flashing)

4、等待升级大约需要 1 分钟左右，直至红/绿灯交叉闪烁表示已完成升级；

摄像头断电，拔出 TF 卡后再次上电查看摄像头是否正常启动

4. Wait about 1 minute , when the Red Light and Green Light flashing alternatively upgrade is finished . Then make the device offline , take out the TF/SD card, plug in power again to check the device working well or not.