

SPY GSM 2000 PIR

Function :

- A, when the body is near, it will auto start the alarm;
- B, The highest sensitivity in the range of 4-5 meters;
- C, Put the alarm cat or paste in a certain height, away from the body within 5 meters within the angular range 120° left and right, as long as people or animals, swaying back and forth in a very short time, induction start.
- D. (option) long press SOS emergency calls can be done, for multiple sets of emergency number
Circular dial, but plugin the ear-set can listen voice
- F. GPS Position Support (The World can support)
Send "w" to the sim numbers and after return a http link and open it can show the following:



using methods:

A) Power on: open the deck lid,insert the SIM card follow the instructions in Figure deck automatically boot.

B) Alarm numbers binded:

i):Communications tools such as mobile phone call connection after 15 seconds,Machine itself through to hear the voice call is binding,Operation is very simple,This way every time should be rebound.

ii): text "alm12345" sent to the machine,the "12345" need be changed , the binded after a successful machine return to SMS, in turn, change the number of backwardness to the machine, can bind mutil numbers, alarm when the machine

will in turn make binding number all the time, the number no longer after answering the call, After binding number this way, I) binding number expire, And the number of binding boot do not need to bind again next time.

C) delete number :

Binding number for I) way, the card is automatically deleted, For ii) binding number, send "amov" delete all number, To end "amov12345" with "12345" to delete the specific number;

D) the query number :

Binding number for ii) way, send "achk" binding number query messages.

3: SOS emergency Settings (option)

I) : text "sos10086" sent to the machine, including "10086" as the need to change the number, binding, in

turn, change the content of backwardness to machine, multiple number, binding machine will cycle in the process of emergency dialing call this set of binding number, each in turn call 2 times, after a among them is answered in a loop, loop to terminate.

Ii) : "del" sent to the machine, remove SOS binding number, also can remove the specific number "del13800" into the machine, including "13800" is the need to change the number to delete;

Iii) : "get" sent to the machine, the query SOS binding number;

三) Rights of privacy protection: send "safeon" open access, only by binding number into the machine, send "safeoff" close permissions, any number can be reached.

F) remote control configuration:

- 1) to send "SMS" to machine, the machine alarm mode to reply messages
- 2) send the "call" to machine, alarm mode switch to a normal phone call
- 3) Send "0000" to the SIM card number after a successful turn off this feature;
- 4) Send "1111" is open induction.

Frequency:

850MHZ, 900MHZ, 1800MHZ, 1900MHZ;

Standby time:

For body sensing:5-7days not for body sensing:15-20days.

Specification:

A, product size: 4.50*3.0*1.40 cm

B, working current: below 10 mA

C, **idle current :below 0.05 mA**

C, sensitivity: 5-8m center angle 90°